





What Is the Relationship Between EZView, EZStation and EZCloud?

Title	What Is the Relationship Between EZView, EZStation and EZCloud?	Version:	V1.2
Product	SMB	Date	11/15/2023

Relationship between EZView, EZStation and EZCloud

Platform	Terminals	Scenarios	Under what circumstances, I need an EZCloud account to log in to view my devices?	Under what circumstances, EZCloud account log in is not necessary?	Where can I sign up an EZCloud account?	Can I configure basic settings?
EZView	Smartphone /Tablet	Local +Remote view	Add by Scan	Add without signup, add by auto search in LAN, add by IP or Domain, add by EZDDNS	EZView login page>sign up	The App itself supports basic configuration settings such as time, image, recording, alarm and so on.
EZStation	Mac or Windows PC	Local +Remote view	Add cloud device	Add local device	Login EZStation first, and then Device Management>Cloud Device>Sign up	Go to Device Management>Operation-click e, and you can log into the device's web page to configure almost all settings. 
EZCloud Website	Web Browser	Remote view only	EZCloud account login only	EZCloud account login only	EZCloud Website: os.ezcloud.uniview.com>sign up ap.ezcloud.uniview.com>sign up (for Asia-Pacific) eu.ezcloud.uniview.com>sign up (for Europe)	Go to Device Management>Operation, click e, and you can log into the device's web page to configure almost all settings. 

Note: For security concerns, a device (NVR/IPC) can be bound to one EZCloud account only, and it cannot be bound to another EZCloud account before the current binding is canceled.

If you want your device(NVR/IPC) to be viewed on multiple phones or PCs, you can share it from the main EZCloud account to other EZCloud accounts, or you can add the device(NVR/IPC) via other ways in which EZCloud account are not required, such as add without sign up, add by public IP address or domain. Or you can simply log in the same EZCloud account on multiple phones or PCs.