

EZView & EZCloud


User Manual

Manual Version: V1.03

Copyright

Copyright 2015 Zhejiang Uniview Technologies Co., Ltd. All rights reserved. No part of this manual may be copied, reproduced, translated, or distributed in any form or by any means without prior consent in writing from our company.

Trademark Acknowledgement


 and other Uniview's trademarks and logos are the property of Zhejiang Uniview Technologies Co., Ltd. Other trademarks, company names and product names contained in this manual are the property of their respective owners.

Disclaimer

- To the maximum extent permitted by applicable law, the product described, with its hardware, software, firmware and documents, is provided on an “as is” basis.
- Best effort has been made to verify the integrity and correctness of the contents in this manual, but no statement, information, or recommendation in this manual shall constitute formal guarantee of any kind, expressed or implied. We shall not be held responsible for any technical or typographical errors in this manual. The contents of this manual are subject to change without prior notice. Update will be added to the new version of this manual.
- Use of this manual and the product and the subsequent result shall be entirely on the user’s own responsibility. In no event shall we be reliable to you for any special, consequential, incidental, or indirect damages, including, among others, damages for loss of business profits, business interruption, or loss of data or documentation, or product malfunction or information leakage caused by cyber attack, hacking or virus in connection with the use of this product.
- Video and audio surveillance can be regulated by laws that vary from country to country. Check the law in your local region before using this product for surveillance purposes. We shall not be held responsible for any consequences resulting from illegal operations of the device.
- The illustrations in this manual are for reference only and may vary depending on the version or model. The screenshots in this manual may have been customized to meet specific requirements and user preferences. As a result, some of the examples and functions featured may differ from those displayed on your monitor.
- Due to uncertainties such as physical environment, discrepancy may exist between the actual values and reference values provided in this manual. The ultimate right to interpretation resides in our company.

Symbols

The symbols in the following table may be found in this manual. Carefully follow the instructions indicated by the symbols to avoid hazardous situations and use the product properly.

Symbol	Description
 NOTE!	Means useful or supplemental information about the use of product.


Contents

1 Introduction	1
Typical Networking	1
Type A	1
Type B	1
Installation and Connection	1
2 Mobile Services	2
How to Get the App	2
Android	2
iOS	2
Log In	3
Start	3
P2P Login	3
Sign Up for a P2P Account	4
Add Devices	5
Service Application	6
Live View	6
Favorites	7
Playback	8
3 Web Services	9
Sign Up	9
Log In	9
Add Device	9
Service Application	10
4 FAQs	11


1 Introduction

Typical Networking

Type A



Type B




Installation and Connection

The terminal devices mentioned in this manual refer to IP cameras or network video recorders (NVR).

For the installation of devices, please refer to the user document delivered with the devices.

The connection of devices is illustrated as follows.



2 Mobile Services

How to Get the App



NOTE!

You are recommended to download the app via Wi-Fi.

Android

- Option one: Search "EZView" on Google Play.
- Option two: Scan the QR code on the device.
- Option three: Download from <http://en.ezcloud.uniview.com>.
- Option four: Log in to the Web interface of the device, click **Setup > Network > EZCloud**, and then scan the QR code on this page.

iOS

- Option one: Access the App Store and search "EZView".
- Option two: Scan the QR code on the device.
- Option three: Download from <http://en.ezcloud.uniview.com>.
- Option four: Log in to the Web interface of the device, click **Setup > Network > EZCloud**, and then scan the QR code on this page.



NOTE!

The following takes iOS as an example to describe how to use the mobile app.

Log In

After opening the app for the first time, you can choose to log in or try it for experience.

- **P2P Login:** Log in to the app using the P2P account, and then you can add, configure or operate the P2P device as required.



- **Start:** Quickly log in to the app without registration, and then you can add, configure or operate the local device as required.




Start

Tap **Start** to enter the **Devices** page.

P2P Login

Make sure you have registered a P2P account before login. For details about the registration, see [Sign Up for a P2P Account](#).



1. Tap **P2P Login** to enter the **P2P Account** page.
2. Tap  in the upper-right corner and then select the desired service area.



NOTE!

You are recommended to choose **中国服务区** if your device is in Chinese Mainland. Otherwise, choose **International**.

3. Enter the username and password of the registered account and then tap **Login**.




Sign Up for a P2P Account

You should sign up for a P2P account first before logging in to add, configure and operate a P2P device.


1. Download and install the app following the instructions.
2. Start the app, and then enter the **P2P Account** page.



NOTE!

You may also register an account later by tapping **Menu** >  **P2P Account**.


3. Tap **Sign up** and complete the registration according to the instructions.
4. You are logged in automatically after the registration succeeded.



Add Devices

If you tap **Start**, the **Devices** page is displayed. Then the step 1 and step 2 can be skipped. If you have logged in to your P2P account, follow the steps below to add devices.

1. On the **P2P Account** page, tap **My Devices**.




2. Tap . You can also tap **Add P2P Device** on the bottom directly to add P2P devices.

3. Select a way to add the device and then enter the device information.

The devices can be added in the following two ways.



- P2P: Scan the QR code on the device or enter the register code manually. This function is available only for the device that supports the P2P function. You can also access the Web interface of the device and click **Setup > Network > EZCloud**. The QR code is displayed on the **EZCloud** page.
- IP: Add the device by entering its IP address.


4. Tap  to save the device information or tap **Start Live View** to view the live video.

Service Application


Live View


1. Start the app and enter the **Live View** page.

2. Tap  or  to open the camera list, select the desired camera(s), and then tap **Start Live View**. You can also operate your device as required by tapping the bottom buttons on the **Live View** page.







Favorites

1. Start the app and enter the **Live View** page.
2. Tap  to add the current view to the Favorites.



Playback

1. Start the app, and then tap **Menu**  > **Playback** to enter the **Playback** page.
2. Tap  or  to open the camera list, select the desired camera(s), and then set the start time.



3 Web Services

Sign Up



NOTE!

You can use the account registered through the mobile app to access the EZCloud website, and vice versa.

1. Open your Web browser, go to <http://en.ezcloud.uniview.com> and then click **Sign up**.
2. Complete the sign-up according to the instructions.



The screenshot shows a web form titled "New User Sign Up". It contains the following fields and elements:

- *Username: [Text input field]
- *Password: [Text input field]
- *Confirm: [Text input field]
- *Email: [Text input field] with an "Acquire" button to its right.
- *Verification Code: [Text input field]
- Two checkboxes: I agree [Service Agreement](#) and I agree to receive service information.
- Two buttons at the bottom: "Sign up" (blue) and "Reset" (grey).

Log In

1. Open your Web browser, go to <http://en.ezcloud.uniview.com> and then click **Login**.
2. Enter the email address and password to enter the **Devices List** page.

Add Device

1. On the **Devices List** page, click  or  to enter the **Add Device** page.
2. Enter the register code and the device name.



NOTE!

You can get the register code of your device by logging in to Web interface of the device. For details about the operation, please refer to the user document.

▶ **Add Device**


Register Code:

Device Name:

- When the device is added successfully, click **Back**. Then the added device is displayed on the **My Cloud Devices** page.



NOTE!

To delete a device, select the device in the device list and then click .

Service Application

Select the desired device(s) and then you can share your device, change the device name, retrieve your password or access the device.

My Cloud Devices

Select	No.	Device Name	Device Type	Device IP	Latest Online Time	Status	Share Device	Change Name	Retrieve Password	Access Device
<input type="checkbox"/>	1	25	NVR	61.164.52.175	8/17/2015 5:48:04 PM	Online	Share	Change	Retrieve	Access


all / inverse 1 in total | per page

- Share Device: Click **Share** and then enter the device information.

▶ **Fill in sharing device information.**

Device Name:

Share To:

Valid Till: 

User Rights:

Description:

- Change Name: Click **Change** to change the device name.

▶ **Change Device Name**

Original Name:


New Name:

- Retrieve password: Click **Retrieve** > **Acquire** for a verification code and then submit the verification code. A temporary password will be displayed on the interface.

▶ **Retrieve Password**

Device Name:

Serial Number:

Valid Date: 

Email:

Verification Code:


- Access Device: Click **Access** to enter the Web interface of the device and operate as required.

4 FAQs

Why can't I access my device (NVR/IP camera) through the WAN?

Check according to the following steps:


1. Check whether you have registered a P2P account. If not, sign up for an account first.
2. Check whether the device is bound to the P2P account according to the following steps:

Open your Web browser, go to <http://en.ezcloud.uniview.com> and then log in using the registered account. Then check whether the device is listed under **My Cloud Devices**. If not, click  on the Web page to add the device again or add it through the mobile app.

3. Check whether EZCloud function is enabled for the device according to the following steps:

- For IP Cameras

Go to the Web interface of your device and click **Setup** > **Network** > **EZCloud**. Make sure EZCloud is enabled and the device status is online. If the device status is displayed as **Online**, the device is connected to the EZCloud server; if displayed as **Offline**, the device is disconnected from the EZCloud server.



- For NVRs

Go to the Web interface of your device and click **Setup > Network > EZCloud**. Make sure EZCloud is enabled and the device status is online. If the device status is displayed as **Online**, the device is connected to the EZCloud server; if displayed as **Offline**, the device is disconnected from the EZCloud server.

