



## **How to Set Up the EZCloud Function?**

Title	How to Set Up the EZCloud Function?	Version:	V1.0
Product	SMB	Date	8/4/2023

# How to Set Up the EZCloud Function?

## Description


**Note:** This method is applicable to most of the scenarios. If the method still cannot solve your problem, it is recommended to consult our Tech Support Team.

[https://global.uniview.com/Support/Service\\_Hotline/](https://global.uniview.com/Support/Service_Hotline/)


## Operating Steps

**Step 1** Connect your camera or NVR to the router directly, and ensure that the IP address of the NVR/camera is in the same network segment with that of your router.

**Step 2** Turn on the EZCloud function from the NVR/camera under **Setup>EZCloud** on the web interface, or under **Menu>Network>Basic>EZCloud** on the NVR's GUI.




Title	How to Set Up the EZCloud Function?	Version:	V1.0
Product	SMB	Date	8/4/2023




**Note:** EZCloud may also show on your camera/NVR as My Cloud or P2P. The settings are all the same.

**Step 3** Scan the QR Code on the EZCloud page to download and install the mobile app if you wish to check the device on your cellphone as well.

**Step 4** Sign up an EZCloud account on EZView, and log in to add this camera/NVR to your cloud account.

**Step 5** Go to **Devices>Add>Scan** to scan the QR code on the EZCloud page to add the device. Enter a name for your device and then click start live view or  on the top right side.





Title	How to Set Up the EZCloud Function?	Version:	V1.0
Product	SMB	Date	8/4/2023

**Note:** *It may take some time for a device to connect to the cloud. If it fails to start a live view on the app, please wait for 2 minutes and check again. You can also pull down and release to refresh the device list and then click the device to start the live view again.*